

XTA Electronics Ltd.


The Design House
 Vale Business Park
 Worcester Road
 Stourport-on-Severn
 Worcs. DY13 9BZ, England
 Tel: 01299 879977 (Intl. +44 1299 879977)
 Fax: 01299 879969 (Intl. +44 1299 879969)






...clone settings using Audiocore

Audiocore may be pressed into service as a means of copying settings from one DP226/DP224 to another unit of the same type when a PCMCIA card is unavailable. The procedure outlined below assumes basic familiarity with Windows 95/98 and with Audiocore itself.

Getting the settings from the original unit.

- ◆ Start Audiocore and plug the unit into the PC, with the unit ID set to 1.
- ◆ Make sure the correct COM port has been selected in the Remote menu, and that the baud rate of the port matches that selected on the DP itself.
- ◆ Before continuing, make sure that Audiocore is set to work with input and crossover memories. This option is set under the 'File' > 'Options' and then the 'Memories' tab. Choose the 'Input and Crossover Memories' scheme.
- ◆ Click on the  New button, on the far left of the toolbar.
- ◆ Choose the option to 'Upload from Connected Units'.
- ◆ After scanning to find the unit, a window will appear offering several connection options. Choose 'Upload Current and Memory Settings'. This will copy all the settings from the unit to the computer.
- ◆ Save the system at this point by choosing 'File' > 'Save' and completing the operation in the standard manner.

Sending the settings to the other unit.

- ◆ If Audiocore is not already running, start it and connect the other unit in place of the original.
- ◆ Check that the unit ID is set to number 1, with the baud rates matching etc...
- ◆ Make sure Audiocore is offline – the  indicator should be grey – if not click the On/Off Line button shown  below here, once.
- ◆ Click on the  On/Off Line button on the toolbar to scan all connected units. A window will appear detailing the DP connected to the PC, with several options available. Click on the button that offers the option to 'Download All Including Memories'.
- ◆ The settings stored on the PC will now be copied to the connected unit.

Note that this procedure will only copy the first nine crossover and input memories from one unit to the other. Up to the first 20 input memories may be copied using the procedure above if the 'Memory Scheme' under the 'File' > 'Options' is set to 'Input Memories Only'. This should be performed independently to the copying of the crossover memories.

Any questions about this Application Note? Ring XTA on the number at the top of this page, or email Waring@xta.co.uk.

Compiled by Waring Hayes.
 R&D / Technical Support